

Feature**Where Found****PROGRAMMABLE
SENSOR OVERRIDE**Hold **-**, turn to Start Times**CYCLE AND SOAK**Hold **+**, turn to Run Times
Press **PRG** to set Soak**DELAY BETWEEN
STATIONS**Hold **-**, turn to Run Times**HIDE PROGRAMS**Hold **-**, turn to Water Days**SOLAR SYNC® DELAY**Hold **+**, turn to Solar Sync**CLIK DELAY**Hold **+**, turn to System Off

Feature

Where Found

TOTAL RUN TIME	Turn to Run Times Press ◀ from Station 1 to view, press PRG to select program
TEST PROGRAM	Hold PRG for 3 seconds
EASY RETRIEVE™	Hold + and PRG to Save Hold - and PRG to Restore
TOTAL RESET	Hold PRG and press RESET button
QUICK CHECK™	Press + , - , ◀ , ▶ together Press + to begin
RUN PROGRAM	Hold ▶ , press PRG to select program